

# Лабораторный регулятор температуры LTR 2500-S

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: [huj@nt-rt.ru](mailto:huj@nt-rt.ru) || сайт: <https://heju.nt-rt.ru/>



The temperature controller LTR 2500 offers an optimum in accuracy and reliability. It is used for temperature controlling of immersion heater, dryer etc...

## Laboratory controller LTR 2500-S

- Low-cost temperature controller
- High-technology
- Suited for all kind of sensor type
- Simple handling
- Self-optimization
- Large LED display
- Breaking capacity 230 V / 10 A

The second microprocessor controller is for security control. It guarantees high security without more difficult handling.

All kind of sensor types are useable (please specify the plug type in case of order). The 4-digits LED display is configurable with 2 digits after comma, that means up to 999,9 or 99,99 and above without comma.

The ranges of temperature are:

Resistance-thermometers Pt 100 and Pt 1000: -200...850°C, KTY: -50...+150°C

Thermocouples:

|               |                |                 |                |
|---------------|----------------|-----------------|----------------|
| Fe-CuNi „L“   | - 200 + 900°C  | Fe-CuNi „J“     | - 210 + 1200°C |
| Cu-CuNi „U“   | - 200 + 600°C  | Cu-CuNi „T“     | - 270 + 400°C  |
| NiCr-Ni „K“   | - 270 + 1372°C | NiCrSi-NiSi „N“ | - 270 + 1300°C |
| Pt10Rh-Pt „S“ | - 50 + 1768°C  | Pt13Rh-Pt „R“   | - 50 + 1768°C  |

For resistance-thermometers a 4-pole Lemos socket is used, which is accepted by "laboratory automatization workgroup". For thermocouples the according thermocouple sockets are used.

Technical datas:

|                                 |                                                                                                                                                                                               |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dimensions:                     | Plastic housing 160 x 82 x 130 mm                                                                                                                                                             |
| LED display:                    | 10 mm high green                                                                                                                                                                              |
| Measurement accuracy:           | for resistance-thermometers 0,1%, for thermocouples 0,4%                                                                                                                                      |
| PID adjustment characteristics: | free selectable or self optimization/-ramp function                                                                                                                                           |
| Sensor protection:              | for resistance-thermometers in case of sensor/short circuit and sensor/cable breach, for thermocouples sensor/cable breach as well as in case of over-/under-running the range of measurement |
| Breaking circuit:               | 230V / 50-60 Hz, 2200 W / 10 A pure ohm resistive load                                                                                                                                        |
| Control elements:               | Control insertion, green luminous on/off switch, sensor socket, line-socket, 1,5 m long cable with plug                                                                                       |
| Security:                       | Additional security controller with second sensor input and shut-down in all poles.                                                                                                           |
|                                 | Standard Type Art.-No.: 439 00 117                                                                                                                                                            |

## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [huj@nt-rt.ru](mailto:huj@nt-rt.ru) || сайт: <https://heju.nt-rt.ru/>